

Partial BACKUP Service Manual

LASER TALON

1993

Volume-2
Electrical

FOREWORD

This Service Manual has been prepared with the latest service information available at the time of publication. It is subdivided into various group categories and each section contains diagnosis, disassembly, repair, and installation procedures along with complete specifications and tightening references. Use of this manual will aid in properly performing any servicing necessary to maintain or restore the high levels of performance and reliability designed into these outstanding vehicles.

This BACKUP DSM manual is to be used ONLY as a BACKUP. Please DO NOT REDISTRIBUTE WHOLE SECTIONS. This BACKUP was sold to you under the fact that you do indeed OWN a GENUINE DSM MANUAL. It CANNOT BE considered a REPLACEMENT (Unless your original manual was lost or destroyed.)

Please See README.TXT or README.HTML for additional information.

Thank you. Gimmiemymanual@hotmail.com



Chrysler Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

GROUP/SECTION INDEX

N00AA--

Electrical

8

Fusible Link, Fuse and IOD or
Storage Connector Location.....

Inspection Terminal Location

Grounding Location

Relay Location

Sensor Location

Control Unit Location

Solenoid, Solenoid Valve Location

Diode Location

Junction Block

Centralized Junction

Harness Connector Inspection

Troubleshooting

Configuration Diagrams

Circuit Diagrams

Engine Electrical

Chassis Electrical

**NOTE: For Engine, Chassis & Body,
refer to Volume-1
"Engine, Chassis & Body".**




RELAY LOCATION

Name	Symbol	Name	Symbol
ABS motor relay	B	Headlight relay	A
ABS power relay	I	Heater relay	E
ABS valve relay	B	Intermittent wiper relay (rear wiper)	J
Automatic seat belt motor relay	J	Intermittent wiper relay (windshield wiper)	F
Blower motor High relay	H	Magnet clutch relay	C
Condenser fan motor High-Low select relay	C	Power window relay	A
Condenser fan motor relay	C	Radiator fan motor relay	A
Dome light relay	J	Starter relay	D
Door lock relay	D	Taillight relay	A
Fog light relay	A	Transistor relay	G
Generator relay	A	Upper beam relay	D




NOTE








The "Name" column is arranged in alphabetical order.

Engine compartment



Interior





SENSOR LOCATION


Name	Symbol	Name	Symbol
Air inlet sensor	I	ISC motor position sensor	C
Air thermo sensor	I	Intake air temperature sensor	A
Barometric pressure sensor	A	Knock sensor	G
Camshaft position sensor	D	Oxygen sensor	E
Crankshaft position sensor	D	Rear speed sensor	L
Engine coolant temperature sensor	F	Throttle position sensor	B
Front speed sensor	J	Vehicle-speed sensor (Reed switch)	H
G-sensor	K	Volume air flow sensor	A

NOTE


The "Name" column is arranged in alphabetical order.

Engine compartment




1.8L Engine














2.0L DOHC Engine <Non-Turbo>




2.0L DOHC Engine <Turbo>













Interior



16A0734











CONTROL UNIT LOCATION




Name	Symbol
4-speed automatic transaxle control module	D
Air conditioning control unit	B
Anti-lock brake control unit	G
Automatic seat belt control unit	F
Door lock control unit	C
Engine control module	E
Auto-cruise control unit	A

NOTE

The "Name" column is arranged in alphabetical order.

Interior





SOLENOID, SOLENOID VALVE LOCATION


Name	Symbol
4-speed automatic transaxle control solenoid valve	A
EGR solenoid	B
Evaporative emission purge solenoid	B, C
Fuel pressure solenoid	C
Turbocharger waste gate solenoid	C

NOTE


The "Name" column is arranged in alphabetical order.

Engine compartment




1.8L Engine





2.0L DOHC Engine <Non-Turbo>



2.0L DOHC Engine <Turbo>








DIODE LOCATION

<Interior-Rear section>

Name	Symbol
Diode (for ABS circuit)	A
Diode (for door ajar-warning circuit)	B

NOTE

The "Name" column is arranged in alphabetical order



CONFIGURATION DIAGRAMS


CONTENTS

N08VA--

Dash Panel	44	Engine Compartment <2.0L DOHC Engine (Turbo)>	40
Engine and Transaxle <1.8L Engine>	42	How to Read Configuration <i>Diagrams</i>	36
Engine and Transaxle <2.0L DOHC Engine>	43	instrument Panel and Floor Console	47
Engine Compartment <1.8L Engine>	36	Interior	48
Engine Compartment <2.0L DOHC Engine (Non-Turbo)>	38	Overall Configuration Diagram	34

OVERALL CONFIGURATION DIAGRAM

N08VB--



16A1334

NOTE

- (1) This illustration shows only the major wiring harness.
 (2) • indicates also equipped at the right side.
 (3) *2 indicates vehicles with ABS.
 (4) • 3 indicates PLYMOUTH Laser.
 (5) *4 indicates EAGLE Talon.

N08VCAI

HOW TO READ CONFIGURATION DIAGRAMS

The wiring diagrams are prepared in such a way that the arrangement of connectors for each vehicle, and the routing of each harness, can be easily understood for each individual wiring section.

Indicates the connector number.

The connector number used is the same number as that used for circuit diagrams; these numbers facilitate the location of the connector positions.

The alphabet letter used as the prefix represents the wiring section in which that connector is used; subsequent numerals make up the number that indicates particular characteristics of that individual connector. As a general rule, numbers are assigned clockwise around the wiring diagram.

Note that, if there is a concentration of connectors with the same form (same number of pins), the connectors' colors are noted in order to facilitate identification.

Example: A-1 2 (Black)

Connector color

Number indicating the connector's characteristics (series number)

Symbol indicating wiring section location of the connector


A: Engine compartment

B: Engine and transaxle

C: Dash panel

D: Instrument panel and floor console

E: Interior




Indicates ground point.
The ground number used is the same number as that used for circuit diagrams; these numbers facilitate the location of the ground points.
For detailed information concerning ground points, refer to P.8-4.

Represents the part concealed by corrugated tubing.

36A0274


ENGINE COMPARTMENT <1.8L Engine>

Connector
symbol

A



- | | | |
|-------|--|---------------------------------------|
| A-01X | IOD or storage connector | } Refer to
CENTRALIZED
JUNCTION |
| A-02X | Taillight relay | |
| A-03X | Headlight relay | |
| A-04X | Power window relay | |
| A-05X | Fog light relay | |
| A-06X | Radiator fan motor relay | |
| A-07X | Generator relay | |
| A-08 | Dual pressure switch
(for air conditioning circuit) | |
| A-09 | Wiper motor | |
| A-10 | Control wiring harness and battery cable
assembly combination | |
| A-11 | Auto-cruise control vacuum pump | |
| A-12 | Brake fluid level sensor | |
| A-13 | — | |
| A-14 | Evaporative emission purge solenoid | |
| A-15 | — | |
| A-16 | EGR solenoid
(Vehicles for California) | |

- | | | |
|-------|--|---|
| A-17X | Condenser fan motor
high-low changeover relay | } Refer to
CENTRALIZED
JUNCTION
(for air
conditioning
circuit) |
| A-18X | Condenser fan motor relay | |
| A-19X | Magnetic clutch relay | |
| A-20X | Condenser | |
| A-21 | Air conditioning relay box | |
| A-22 | — | |
| A-23 | — | |
| A-24 | Washer motor | |
| A-25 | Front side marker light (Left side) | |
| A-26 | Headlight (Left side) | |
| A-27 | } Horn (Left side) | |
| A-28 | | |
| A-29 | Engine compartment wiring harness and fog
light sub harness combination | |
| A-30 | Fog light (Left side) | |
| A-31 | Condenser fan motor
(for air conditioning circuit) | |
| A-32 | Front combination light (Left side) | |



To engine and transaxle
(connector symbol □)

- A-33 —
- A-34 —
- A-35 Volume air flow sensor
- A-36 Automatic transaxle fluid temperature sensor
- A-37 Kickdown servo switch <A/T>
- A-38 Pulse generator <A/T>
- A-39 Radiator fan assembly
- A-40 Front combination light (Right side)
- A-41 Radiator water level switch
- A-42 Fog light (Right side)
- A-43 Engine compartment wiring harness and fog light sub harness combination
- A-44 } Horn (Right side)
- A-45 }
- A-46 Headlight (Right side)
- A-47 Front side marker light (Right side)
- A-48 —





36A0270

- A-49 } Control wiring harness and engine
- A-50 } compartment wiring harness combination
- A-51 —
- A-52 Fuel pump check connector
- A-53 Noise condenser
- A-54 Defogger relay
- A-55 —
- A-56 —
- A-57 Ignition timing adjustment connector

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: ■), refer to P.8-4.
- (3) "—" means that the connector with code-number is not used.
- (4) IOD: Ignition Off Draw

ENGINE COMPARTMENT <2.0L DOHC Engine (Non-Turbo)>



A-01X IOD or storage connector

A-02X Taillight relay

A-03X Headlight relay

A-04X Power window relay

A-05X Fog light relay

A-06X Radiator fan motor relay

A-07X Generator relay

A-08 Dual pressure switch
(for air conditioning circuit)

A-09 Wiper motor

A-10 Control wiring harness and battery cable
assembly combination

A-11 Auto-cruise control vacuum pump

A-12 Brake fluid level sensor

A-13 —

A-14 Evaporative emission purge solenoid

A-15 —

A-16 EGR solenoid
(Vehicles for California)

Refer to
CENTRALIZED
JUNCTION

A-17X Condenser fan motor
high-low changeover relay

A-18X Condenser fan motor relay

A-19X Magnetic clutch relay

A-20X Condenser

A-21

A-22 Air conditioning relay box

A-23 ABS front speed sensor (Left side)

A-24 Washer motor

A-25 Front side marker light (Left side)

A-26 Headlight (Left side)

A-27 Horn (Left side)



A-28 }
A-29 Engine compartment wiring harness and fog
light sub harness combination

A-30 Fog light (Left side)

A-31 Condenser fan motor
(for air conditioning circuit)

A-32 Front combination light (Left side)

Refer to
CENTRALIZED
JUNCTION
(for air
conditioning
circuit)




- A-33 } Hydraulic unit
- A-34 }
- A-35 Volume air flow sensor
- A-36 Automatic transaxle fluid temperature sensor
- A-37 Kickdown servo switch <A/T>
- A-38 Pulse generator <A/T>
- A-39 Radiator fan assembly
- A-40 Front combination light (Right side)
- A-41 Radiator water level switch
- A-42 Fog light (Right side)
- A-43 Engine compartment wiring harness and fog light sub harness combination
- A-44 Horn (Right side)
- A-45 }
- A-46 Headlight (Right side)
- A-47 Front side marker light (Right side)
- A-48 —

- A-49 } Control wiring harness and engine
- A-50 }
- A-51 } compartment wiring harness combination
- A-51 ABS front speed sensor (Right side)
- A-52 Fuel pump check connector
- A-53 Noise condenser
- A-54 Defogger relay
- A-55 —
- A-56 Engine speed adjustment connector
- A-57 Ignition timing adjustment connector

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness
- (2) For details concerning the ground point (example: 1), refer to P.8-4.
- (3) "—" means that the connector with code-number is not used.
- (4) The wiring indicated by the • I symbol is applicable to vehicles with ABS and the wiring indicated by the *2 symbol is applicable to vehicles without ABS.
- (5) IOD : Ignition Off Draw

ENGINE COMPARTMENT <2.0L DOHC Engine (Turbo)>

Connector
symbol**A**

A-01X IOD or storage connector
 A-02X Taillight relay
 A-03X Headlight relay
 A-04X Power window relay
 A-05X Fog light relay
 A-06X Radiator fan motor relay
 A-07X Generator relay
 A-08 Dual pressure switch
 (for air conditioning circuit)
 A-09 Wiper motor
 A-10 Control wiring harness and battery cable
 assembly combination



Refer to
CENTRALIZED
JUNCTION

A-11 Auto-cruise control vacuum pump
 A-12 Brake fluid level sensor
 A-13 Control wiring harness and solenoid valve
 harness assembly combination
 A-14 Evaporative emission purge solenoid
 A-15 Dual pressure solenoid valve
 A-16 OR solenoid
 (vehicles for California)

A-17X Condenser fan motor
 high-low changeover relay
 A-18X Condenser fan motor relay
 A-19X Magnetic clutch relay
 A-20X Condenser

Refer to
CENTRALIZED
JUNCTION
(for air
conditioning
circuit)

A-21 Air conditioning relay box
 A-22 }
 A-23 ABS front speed sensor (Left side)
 A-24 Washer motor
 A-25 Front side marker light (Left side)
 A-26 Headlight (Left side)
 A-27 }
 A-28 Horn (Left side)
 A-29 Engine compartment wiring harness and fog
 light sub harness combination
 A-30 Fog light (Left side)
 A-31 Condenser fan motor
 (for air conditioning circuit)
 A-32 Front combination light (Left side)



- A-33 } Hydraulic unit
- A-34 }
- A-35 Volume air flow sensor
- A-36 Automatic transaxle fluid temperature sensor
- A-37 Kickdown servo switch <A/T>
- A-38 Pulse generator <A/T>
- A-39 Radiator fan assembly
- A-40 Front combination light (Right side)
- A-41 Radiator water level switch
- A-42 Fog light (Right side)
- A-43 Engine compartment wiring harness and fog light sub harness combination
- A-44 Horn (Right side)
- A-45 }
- A-46 Headlight (Right side)
- A-47 Front side marker light (Right side)
- A-48 Turbocharger waste gate solenoid
- A-49 } Control wiring harness and engine
- A-50 } compartment wiring harness combination

- A-51 ABS front speed sensor (Right side)
- A-52 Fuel pump check connector
- A-53 Noise condenser
- A-54 Defogger relay
- A-55 Resistor
- A-56 Engine speed adjustment connector
- A-57 Ignition timing adjustment connector

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: **1**), refer to P.8-4.
- (3) The wiring indicated by the • 1 symbol is applicable to vehicles with ABS and the wiring indicated by the • 2 symbol is applicable to vehicles without ABS.
- (4) IOD: Ignition Off Draw

LIGHTING SYSTEM

SPECIFICATIONS

GENERAL SPECIFICATIONS

NOBIB--

Items	Specifications
Exterior lights	
Headlight	W 65/55
Fog light	W 25
Front combination light	
Turn-signal and position light	C P 24/2.2
Front side marker light	CP 3
Rear side marker light	CP 3
Rear combination light	
Tail light* ¹	C P 32/2 (2057)* ¹
Turn-signal, stop and taillight* ¹	C P 32/2 (2057)* ¹
Turn-signal light* ²	CP 32 (1 156)* ²
'Stop and tail light"*	C P 32/2 (2057)* ²
Back-up light* ¹	W 2 7 "
Back-up light* ²	CP 21* ²
License plate light	W 5
High-mounted stop light	W 27 or 5* ³
Interior lights	
Front dome light	
Dome light	W 8
Stop light	W 8
Foot light	W 3.4
Glove compartment light	W 3.4
Luggage compartment light	W 5

NOTE

- *¹ PLYMOUTH Laser
- *² EAGLE Talon
- *³ Vehicles with rear air spoiler
- The values in parentheses denote SAE trade numbers.

SERVICE SPECIFICATIONS

NOBIC--


Items	Specifications
Limit	
Headlight intensity	20,000 cd or more

TROUBLESHOOTING

HEADLIGHT

CIRCUIT DIAGRAM

Vehicles without daytime running light



NOBIIHH

Wiring Diagram for Rear Stop Light System

WITH AUTO-CRUISE CONTROL

WITHOUT AUTO-CRUISE CONTROL

STOP LIGHT SWITCH C-03

OPEN CONNECTOR C-02

REAR COMBINATION LIGHT (LEFT SIDE)

REAR COMBINATION LIGHT (RIGHT SIDE)


HIGH MOUNTED STOP LIGHT

E-29, E-27, E-20, E-18, E-65, E-17

Wiring Details:

- WITH AUTO-CRUISE CONTROL:** The Stop Light Switch (C-03) is connected to the Open Connector (C-02). The Open Connector (C-02) is connected to the Rear Combination Light (Left Side) and the Rear Combination Light (Right Side). The High Mounted Stop Light is connected to the Rear Combination Light (Right Side).
- WITHOUT AUTO-CRUISE CONTROL:** The Stop Light Switch (C-02) is connected to the Rear Combination Light (Right Side). The High Mounted Stop Light is connected to the Rear Combination Light (Right Side).

* Indicates vehicles with rear spoiler



SERVICE ADJUSTMENT PROCEDURES

NO811AF

HEADLIGHT AIMING

PRE-AIMING INSTRUCTIONS


1. Test dimmer switch operation.
2. Observe operation of high beam light mounted in instrument cluster.
3. inspect for badly rusted or faulty headlight assemblies. These conditions must be corrected before a satisfactory adjustment can be made.
4. Place vehicle on a level floor.
5. Bounce front suspension through three (3) oscillations by applying body weight to hood or bumper.
6. Inspect tire inflation.
7. Rock vehicle sideways to allow vehicle to assume its normal position.
8. If fuel tank is not full, place a weight in trunk of vehicle to simulate weight of a full tank [3 kg (6.5 lbs.) per gallon].
9. There should be no other load in the vehicle other than driver or substituted weight of approximately 70 kg (150 lbs.) placed in driver's position.
10. Thoroughly clean headlight lenses.

VERTICAL ADJUSTING

Insert the screwdriver into the vertical adjusting hole, and turn it clockwise or counterclockwise to bring the bubble of the vertical angle gauge to the center.

NOTE

The beam angle will change about $0^{\circ}19'$ with one mark.








HORIZONTAL ADJUSTING

1. After pulling out the stopper upward, press gear (B) forward to disengage it from gear (A).
2. Insert the screwdriver into the horizontal adjusting hole, and adjust the horizontal angle.
3. After adjustment, align the "0" mark of gear (B) to the center line, and press in the stopper for locking.

NOTE

The beam angle will change about $0^{\circ}36'$ with one mark.





AIMING WITH SCREEN HEADLIGHT AIM PREPARATION

- 1 Measure the center of the headlight bulb as shown in the illustration.
- 2 Place vehicle on a known level floor 3m (9.8 feet) from aiming screen or light colored wall. Four lines of adhesive tape or like are required on screen or wall:
 - (1) Position a vertical tape so that it is aligned with the vehicle center line.
 - (2) Position a horizontal tape with reference to center line of headlight bulb.
 - (3) Position a vertical tape on the screen with reference to the center line of each of headlights bulb.

VISUAL HEADLIGHT ADJUSTMENT

1. A properly aimed lower beam will appear on the aiming screen 3m (9.8 feet) in front of the vehicle. The shaded area as shown in the illustration indicates high intensity zone.
2. Adjust low beam of headlights to match the low beam pattern of the right and left headlights.

** Caution

When adjusting one headlight, the other headlight should be turned off if possible. If this is not possible, do not cover the other headlight for more than three minutes while it is turned on. Otherwise, heat from the bulb may warp the headlight lens.**

Vertical Adjusting

1. Check the position of the level bubble to confirm that it is within the range as shown in the illustration.
2. Confirm that the beam irradiated on the screen is the same as the specified beam pattern.

If it is not the same, adjust the vertical angle with the vertical adjusting screw so that it becomes the specified beam pattern.

NOTE

If the visual headlight adjustment at low beam is made, the adjustment at high beam is not necessary.


LUMINOUS INTENSITY MEASUREMENT

Measure the luminous intensity of headlights with a photometer in accordance with the instruction manual prepared by the manufacturer of the photometer and make sure that the luminous intensity is within the following limit.

Limit: 20,000 cd or more


NOTE

- (1) When measuring the luminous intensity of headlight, keep the engine at 2,000 rpm and have the battery charged.
- (2) If there are specific regulations for luminous intensity of headlights in the region where the vehicle is operated; make sure that the intensity conforms to the requirements of such regulations.


**FOG LIGHT AIMING**

NOB11EA


1. Place vehicle on a known level floor 7.6 m (25 feet) from aiming screen or light colored wall.
2. Use adjusting screw to adjust the top end of high intensity zone to dimension A.

**HEADLIGHT BULB REPLACEMENT**

- 1 Pull out the socket cover.



2. Remove the valve mounting spring, and pull the valve out toward you together with the connector.
3. Disconnect the bulb from the connector.



Caution

1. Never hold the halogen light bulb **with** a bare hand, dirty glove, etc.
2. If the glass surface is **dirty**, be sure to clean it with alcohol, paint thinner, etc., and install it after drying it thoroughly.
4. Be sure to attach the cap.


NOTE

Be sure to install the cap securely because, if it is not, an insecure installation could cause such problems as clouding of the lens, or intrusion of moisture to inside the light unit

HEADLIGHT AND FRONT SIDE MARKER LIGHT

NO8LJAQ

REMOVAL AND INSTALLATION




Removal steps

- + 1. Front side marker light
- 2. Headlight

NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ● 4: Refer to "Service Points of Installation"



SERVICE POINTS OF INSTALLATION


1. INSTALLATION OF FRONT SIDE MARKER LIGHT

Insert the boss of the front side marker light into the clip areas of the front fender, and insert the ribs of the front side marker light into the mounting holes on the headlight side. Then, mount the front side marker light with the mounting screws.

REAR COMBINATION LIGHT


REMOVAL AND INSTALLATION

<EAGLE Talon>



18A0927

<PLYMOUTH Laser>



18A0926

Removal steps

- ◆◆ 1. Back-up light
- ◆◆ 2. License platelight
- ◆◆ 3. Rear panel garnish
- ◆◆ 4. Lid C (Lid D when the right rear combination light is removed or installed)
- 4 5. Rear combination light

NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ◆◆: Refer to "Service Points of Removal".
- (3) ●+: Refer to "Service Points of Installation".

SERVICE POINTS OF REMOVAL

1. REMOVAL OF BACK-UP LIGHT

Refer to GROUP 23 - Garnishes.


3. REMOVAL OF REAR PANEL GARNISH

Refer to GROUP 23 - Garnishes.

SERVICE POINTS OF INSTALLATION

5. INSTALLATION OF REAR COMBINATION LIGHT

Mount the rear combination light by tightening the nuts in the sequence illustrated.




16A0820

HIGH MOUNTED STOP LIGHT

REMOVAL AND INSTALLATION

NOBIKAK


<Vehicles without rear air spoiler>



Removal steps

1. Clip
2. High mounted stop light cover
3. High mounted stop light lens and bracket
4. Gasket

<Vehicles with rear air spoiler>



Removal steps

- ◆◆ 1. High mounted stop light unit
2. Liftgate trim
3. Wiring harness connector
4. Socket

NOTE

1) Reverse the removal procedures to reinstall.
 2) ◆◆: Refer to "Service Points of Removal".

SERVICE POINTS OF REMOVAL

2. REMOVAL OF LIFTGATE TRIM <Vehicles with rear air spoiler>

Refer to GROUP 23—Trims.